



Jak vyjmout zabudovanou baterii


HL-EL150RC / HL-EL151RC




HL-EL050RC



TL-LD620-R / TL-LD635-R



TL-LD700-F/R / TL-LD710-F/R / TL-LD720-F/R



SL-LD140RC-F/R

